

TECHNICAL REQUIREMENTS VICTOR MONGE SERRANITO

“Fascinación del Flamenco - Danza & Guitarra”

Serranito / Dancer men / Voice women / Guitar / 2º Guitar / Percussion

Stage setting

1 Cyclorama retroproyection 12X8 metre..
1 Gauze black 12X8 metre.
1 Proyector Slides
Xenon 800-1000 Wativos.
Lens Big Angle 35-38 m/m

Stage requirements

7 Chairs

Sound

P.A. minimum 4.000 W (Meyer, EAW, or equivalent)
Control: Mixer Soundcraft 8000 32channels or equivalent
2 Equalizers 31bands Klark- Teknik
1 Intercom.
1 Reverb Lexicon PCM 70
1 CD

Monitor: 1 Mixer monitor 32/12
2 Side-Fill Biamplicado
13 Floor-monitor
10 Equalizers 31 bands Klark- Teknik
1 Reveb SPX 900.

Dressing Room:

1 For Victor Monge with bathroom.
1 For the two guitars with bathroom.
1 For the dance.
1 For the rest with bathroom.

Catering for artists.

Requirements for: Hall with capacity of 1.000 – 2.000 seats

Mikes: 3 Mikes AKG condense.for drums.
3 Mikes AKG condense or Shure. SM57 Beta for guitars.
3 Mikes Shure SM 58 for voices.
1 Mike Wireless SM78 for voice.
2 Mikes AKG D112 for drums.
3 Mikes Sennheiser 441 for drums.
1 Mike Shure SM57 for drums.
4 Mike PZ Ancrom for floor.
5 D.I. Box active for bass. And Keys

Lighting

1 Mixer lighting
36 proyectors PC 1KW
12 Proyectors 1 KW 15/28
16 Asymetrical Panorama's 1 KW
1 Spot-light
Dimmers total regulation

Colors filter: Purple
Blue
Red
Pink
Amber

List chanel

1	KICK	AKG D112
2	SNARE	SHURE SM 57
3	H/H	AKG CONDENSE
4	TOM 1	SENNHEISER 441
5	TOM 2	SENNHEISER 441
6	TOM 3	SENNHEISER 441
7	BOX	AKG D112
8	OH	AKG CONDENSE
9	OH	AKG CONDENSE
10	BASS	D.I. BOX
11	GUITAR	AKG CONDENSE OR SHURE BETA57
12	GUITAR	AKG CONDENSE OR SHURE BETA57
13	GUITAR	AKG CONDENSE OR SHURE BETA57.
14	VOICE	WIRELESS SM58
15	VOICE DANCE	SHURE SM58
16	VOICE DANCE	SHURE SM58
17	VOICE SPEAKER	SHURE SM58.
18	PIANO LEFT	D.I. BOX
19	PIANO RIGHT	D.I. BOX
20	KEY LEFT	D.I. BOX
21	KEY RIGHT	D.I. BOX
22	MICRO CONTACTO	ANCROM PZ
23	MICRO CONTACTO	ANCROM PZ
24	MICRO CONTACTO	ANCROM PZ
25	MICRO CONTACTO	ANCROM PZ
26	CD	
27	CD	
28	RETURN PCM 70	
29	RETURN PCM 70	

MIXER MONITOR

1	SIDE-FILL.	2XBiamplificado
2	GUITAR LEADER	2XFloor-monitor
3	BAJO.	1XFloor-monitor
4	GUITAR 1.	1XFloor-monitor
5	GUITAR 2.	1XFloor-monitor
6	DRUMS	1XFloor-monitor
7	DANCE	2XFloor-monitor
8	DANCEFRONT	2XFloor-monitor
9	VOICES	1XFloor-monitor
10	PIANO	1XFloor-monitor
11	RETURN SPX 900	

Technical monitor 1XFloor-monitor